

GENEE **VISION**[®] Visualisers




Classroom for the Future



Classroom for the Future

GENEE SOLUTIONS
INDIA PRIVATE LIMITED
An ISO 9001:2008 certified company

GENEE **VISION**[®] Visualisers



For more Information...
Call us: 011-49554955

Tel: 011-49554955

@ Email: info.india@geneeworld.com, sales.india@geneeworld.com

www Website: www.genee-india.com, www.geneeworld.com

Fax: 011-49554956

Post - B-15, Ram Dutt Enclave, (Near Uttam Nagar East Metro Station), Uttam Nagar, New Delhi-110059, India

Quick set up guide



Quick set up guide for **Genee Vision** visualisers

6100 • 8100 • Elite

Quick guide contents

Now that you have received your visualiser you will want to get started straight away.

Visualisers can be used independently through a direct connection to a projector or monitor screen, or can be linked to a computer to integrate with software applications and interactive whiteboards.

Over the next few pages you will be shown how to connect and operate your visualiser.

1. Package contents

2. Connectivity identification

3. Connecting to a projector

4. Using the features

5. Switching projector inputs

6. Loading the software

7. FAQ

8. Support


Package contents



Visualiser unit



Remote control
(stored in base of unit)



Software CD



S-VHS cable

Composite A/V phono cable

Power supply adapter

3.5mm jack to stereo phono sockets

RS232 to PS2 cable

IEC mains cable

VGA male-male

RS232 serial cable

USB A-A lead

Connectivity identification

Rear panel GV6100 / 8100



Side panel GV6100 / 8100




Rear panel GV Elite



Connecting to a projector


You can simply use your visualiser as a presentation tool with a single (VGA) connection to a projector or display screen:



You should now be able to see any 2D or 3D object placed under the camera, and use the built-in functions.

Using the features

The visualisers have built-in functions that can be operated either from the control panel buttons or from the remote control.



Buttons and remotes may vary on different models



Button functions on the GV6100 / 7100 / 8100 / 9100 visualiser/remote

POWER	Control the visualiser On/Off Press and hold two seconds to power off visualiser	CCD/PC1/PC2 S-VIDEO/VIDEO LAMP AUTO	CCD/RGB input signal selection Video input signal selection Control the arm lights and back light To auto adjust white balance and auto focus
Mir	Reverse the image	+ T/W -	Increase and decrease the magnification
Frz	Freeze the image	B&W	Add and remove colour (remote)
Neg	Display negative image	Save	Temporarily save images to Flash file (remote)
Title	Freeze the top 1/8 of the screen	Recall	View saved images (remote)
D./S.	Switch between static and dynamic modes	Rotate	90°, 180°, 270° image rotation (GV9100 only)
Far/Near	Focus far or near	XGA	Projector type
Split	Image Split function	Text	Sharpens image
Ppw	Control the projector On/Standby (with RS232 link)	Red +/-	Alter colour balance
Pin	Projector input signal selection	Blue +/-	Alter colour balance
& ↓	Move the image up/down	Bright +/-	Alter brightness of image
		Scroll ↑ / ↓	Moves camera head
		Projector power	Control projector if linked
		Projector input	Input selection
		Remarks:	Frz, Title, D./S. and Split functions are only available on PROJECTOR OUT port with CCD camera models (GV6100, 7100 & 8100) and both PROJECTOR and USB ports with CMOS camera models (GV9100 & Elite).


Buttons on the GV Elite



Switching projector inputs

By linking your visualiser to a PC or laptop you can switch projector inputs using the 'CCD/PC1/PC2' button on the unit's control panel. This integrates seamlessly with an interactive whiteboard and only requires a second VGA lead:

When you press the CCD/PC1/PC2 button it will change from blue to green and the computer desktop image will be shown (you may have to clone the screen when linked to a laptop).




If your PC is connected to a splitter box, simply connect the VGA lead that comes from the wall-plate socket into the visualiser's 'Projector' socket, then use another VGA lead to link the splitter box to the visualiser's 'Computer In' socket. (The visualiser itself can be used as a splitter box!).

Loading the software

The accompanying disk has essential software for enabling your computer to recognise the visualiser and capture images, both still and moving. This will be done through the USB connecting lead.

The driver for your operating system must be installed before connecting the USB lead. The set-up wizard will take you through the process.

VideoCap and Genee Toolbar are programs that will give you live camera windows and white-board tools on your desktop, allowing you to annotate over them or capture in common image and video formats that can be incorporated into different applications.



The disk also contains additional information, including user guides and training videos.

FAQ

1. I cannot get an image through the projector

- i. Is the power connected and switched on (see step 3)
- ii. Have you taken the lens cap off?
- iii. Is the VGA lead connection from the projector plugged into the visualiser's 'projector' socket?

2. How do I switch to my desktop image on my board?

- i. Check that your VGA lead is connecting your visualiser to your computer (see step 3).
- ii. Press the CCD/PC1/PC2 button so that it turns green (see step 5)
- iii. Press the same button (until it goes to blue) to return to the visualiser.

3. How do I annotate over my visualiser images?

- i. Check that the supplied VideoCap and/or Genee Toolbar has been installed
- ii. Check that the supplied USB lead is connecting the visualiser to your computer
- iii. Open either the VideoCap or Genee Toolbar software to get a live video window (you may have to select the USB 2861 camera if there is a choice).
- iv. You can now use your IWB tools or the Genee Toolbar tools to annotate over

4. Will this work with any board?

Yes.

5. Can I save these images?

VideoCap and Genee Toolbar will save both still images and video images. You can also use generic programs such as Microsoft MovieMaker or insert images directly onto Word pages, for example, by going to the 'insert from camera or scanner' command.

Please contact technical@geneeworld.com if the problem persists.

Support

Free technical helpline

Tel: 011-49554955

Fax: 011-49554956

Email: info.india@geneeworld.com,
sales.india@geneeworld.com

Website: www.genee-india.com,
www.geneeworld.com

Other products available to use with your visualiser:

